



**REMOVE EACH FELT PAD  
FROM THEIR RESPECTIVE  
VELCO STRIP**



**FOLD EACH D-RING  
INSIDE AND FASTEN TO  
THE VELCRO STRIP**



**FOLD THE SECOND RING  
AND FASTEN SO IT IS  
ALIGNED AND BOTH ENDS  
ARE THE SAME LENGTH**